



Grill WPG250 220V/60Hz

02.06.3846



Knob de controle de temperatura

028626

WARING
COMMERCIAL

02.06.3847



Botão Liga/Desliga

029478



02.06.3848



LED indicador de temperatura

029941

02.06.3849



Termostato

029942

WARING
COMMERCIAL

02.06.3850



Tampa superior de níquel cromado

029945

02.06.3851



Resistência do platen superior 6A

029961

WARING
COMMERCIAL

02.06.3852



Platen superior ondulado

029967

WARING
COMMERCIAL

02.06.3853



Platen superior liso

029968

WARING
COMMERCIAL

02.06.3854



Platen inferior ondulado

029971

WARING
COMMERCIAL

02.06.3855



Platen inferior liso

029972



02.06.3856



Resistência inferior 8A

029977

WARING
COMMERCIAL

02.06.3857




Protetor térmico

029996



02.06.3858




Chicote da fiação da chapa

030003



02.06.3859



Chicote da fiação do platen

030004



Suporte técnico

Estevão Moraes (21)3147-1043

Adriano Belarmino (21)3147-1065

Marcelo Sarmiento (21)3147-1022

